

#400-RAM ROCK ACCENT MEDIA

For use with model #CLW-40

If converting to propane, complete the conversion before installing the media kit. Follow the conversion instructions included with the kit.

CAUTION: Do not set rock accent media directly on top of burner ports. Do not block pilot assembly. This could cause a potentially hazardous situation.

This kit contains:

(27) rocks

1. Use the provided picture for a suggested configuration.
2. Rocks cannot go on the burner, cover porting, or cover air channels. Rocks may only be placed in the perimeter zone. Not all rocks may be used based on desired look.

