

# #800-BAK BEACH ACCENT KIT

For use with model #CLW-72

**NOTE:** Log and rock numbers are located on the bottom of each media accent piece. Refer to the following directions for proper placement. Your components may look different than the ones shown.

**NOTE:** If converting to propane, complete the conversion before installing the media kit. Follow the conversion instructions included with the kit.

**NOTE:** Rock accent medias may be moved or removed to prevent potential sooting.

**CAUTION:** Do not set accent media directly on top of burner ports. Do not block pilot assembly. This could cause a potentially hazardous situation.

This kit contains:

(8) Driftwood logs

(16) Rocks

1. Install rocks as shown below.
2. Install the logs as shown below.
3. Place the logs on top of the perimeter media, if installed.
4. Ensure logs and rocks do not impede flame when placed across the burner.

